


★ Manual adjustment can be done by screwing for example an M4×20 L screw in the M4 thread or pushing in a rod etc. there.

Model Numbers		Dimensions mm (Inches)														
	Α	В	С	D	Е	F	Н	J	K	L	N	Р	Q	S	Т	U
EF*G-02	96 (3.78)	76.2 (3.00)	9.9 (.39)	38.1 (1.50)	106 (4.17)	82.6 (3.25)	11.7 (.46)	46.3 (1.82)	195 (7.68)	81 (3.19)	66 (2.60)	108 (4.25)	8.8 (.35)	14 (.55)	65 (2.56)	1
EF*G-03	125 (4.92)	101.6 (4.00)	11.7 (.46)	50.8 (2.00)	130 (5.12)	101.6 (4.00)	14.2 (.56)	61.8 (2.43)	212 (8.35)	98 (3.86)	85 (3.35)	125 (4.92)	11 (.43)	17.5 (.69)	84 (3.31)	2



★ Manual adjustment can be done by screwing for example an M4×20 L screw in the M4 thread or pushing in a rod etc. there.

Model Numbers		Dimensions mm (Inches)															
	Α	В	С	D	Е	F	Н	J	K	L	N	Р	Q	S	Т	U	V
EF*G-06	180	146.1	17	73.1	174	133.4	20.3	99	244	130	105	7	157	17.5	26	103.5	16
	(7.09)	(5.75)	(.67)	(2.88)	(6.85)	(5.25)	(.80)	(3.90)	(9.61)	(5.12)	(4.13)	(.28)	(6.18)	(.69)	(1.02)	(4.07)	(.63)
EF*G-10	244	196.9	23.5	98.5	228	177.8	25	144.5	274	160	137	10	187	21.5	32	135	18
	(9.61)	(7.75)	(.93)	(3.88)	(8.98)	(7.00)	(.98)	(5.69)	(10.79)	(6.30)	(5.93)	(.39)	(7.36)	(.85)	(1.26)	(5.31)	(.71)